


Engine Stop Switch

The two position engine stop switch (1) is next to the throttle grip. In RUN, the engine will operate. In the OFF position, the engine will not operate. This switch is intended primarily as a safety or emergency switch and should normally remain in RUN.

NOTE:

- * If your motorcycle is stopped with the ignition switch ON and the engine stop switch OFF, the headlight and taillight will still be on, resulting in battery discharge.



(1) Engine stop switch