

Tires – Check the air pressure and the tires for wear or damage.

Throttle operation – Check throttle operation, cable routing and free play.

Correct or replace if necessary.

Lighting – See if all lights operate properly.

Drive chain – Check condition of drive chain and measure the chain tension. Adjust if the chain tension is incorrect. Lubricate if it appears dry. Replace if it is badly worn or damaged.

---

Pneus – Vérifier la pression des pneus et leur état d'usure ou d'endommagement.

Fonctionnement de la poignée des gaz – Vérifier le bon état de fonctionnement de la poignée des gaz, pose des câbles, et jeu libre. Régler ou remplacer, si nécessaire.

Eclairage – S'assurer que tous les feux fonctionnent correctement.

Chaîne de transmission – Mesurer le jeu; la dureté d'articulation due à une lubrification négligée ou autres conditions essentielles à la bonne conduite.