

# MAINTENANCE SCHEDULE

The following Maintenance Schedule specifies all maintenance required to keep your motorcycle in peak operating condition. Maintenance work should be performed in accordance with standards and specifications of Honda by properly trained and equipped technicians. Your authorized Honda dealer meets all of these requirements. Perform the Pre-ride Inspection (page 43) at each scheduled maintenance period.

I: INSPECT AND CLEAN, ADJUST, LUBRICATE OR REPLACEMENT IF NECESSARY

C: CLEAN      R: REPLACE      A: ADJUST      L: LUBRICATE

ITEM		FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING (NOTE 1)					REFER TO PAGE
				x1,000 km	1	4	8	12	
				x1,000 mi	0.6	2.5	5	7.5	
			NOTE	MONTH	6	12	18		
*	FUEL LINE				I	I	I	-	
*	FUEL STRAINER SCREEN				C	C	C	-	
*	THROTTLE OPERATION				I	I	I	66	
**	OIL PUMP AND OIL LINE				I	I	I	-	
*	AIR CLEANER		(NOTE 2)		C	C	C	-	
	SPARK PLUG			EVERY 2,000 km = C, EVERY 4,000 km = R				64	
**	DECARBONIZING					C		-	
	ENGINE IDLE SPEED				I	I	I	68	
*	RADIATOR COOLANT		(NOTE 3)			I		21	
*	COOLING SYSTEM					I		-	