

(Ref.No.) Description	Function
(9) M mode indicator (orange) (NSS250EX)	Lights when the 6-speed manual mode is selected (page 83).
(10) D mode indicator (green) (NSS250EX)	Lights when the D mode is selected in the automatic shift mode (page 85).
(11) S mode indicator (orange) (NSS250EX)	Lights when the S mode is selected in the automatic shift mode (page 85).
(12) RESET button	This button is used to reset the tripmeter to zero (0) (page 25). This button is also used to reset the oil change indicator (page 31) and adjust the time (page 28).
(13) Oil change indicator (orange)	Lights when specified maintenance interval for engine oil change is reached (page 31).
(14) Mode button	The button is used to select the odometer or the tripmeter A or B (page 25), to adjust the time (page 28).