


Shifting Restriction:

If the system determines that the travel-device will be damaged or there will be over revving of the engine while shifting, the shift indicator (1) flashes and shifting can not be done.

- If you have any trouble shifting or hear a noise, see your Honda dealer.
- When riding on a slippery road, shifting down may cause slip.



(1) Shift indicator