

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								REFER TO PAGE
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
		NOTE	MONTH								
* FUEL LINE						I		I		I	—
* THROTTLE OPERATION						I		I		I	154
AIR CLEANER		NOTE (2)					R			R	138
CRANKCASE BREATHER		NOTE (3)			C	C	C	C	C	C	143
SPARK PLUG					I	R	I	R	I	R	151
* VALVE CLEARANCE					I		I		I		—
ENGINE OIL					R	R	R	R	R	R	144
* ENGINE OIL STRAINER SCREEN							C		C		149
* ENGINE IDLE SPEED					I		I		I		—
RADIATOR COOLANT		NOTE (5)					I		I	R	40
* COOLING SYSTEM							I		I		—
* SECONDARY AIR SUPPLY SYSTEM							I		I		—