

## **MAINTENANCE**

Page

72	MAINTENANCE
73	Maintenance Schedule
76	Tool kit
77	Serial Numbers
78	Colour Label
78	Maintenance Precautions
79	Air Cleaner
80	Belt Case Air Cleaner
83	Crankcase Breather
84	Engine Oil
87	Spark Plug
89	Idle Speed
90	Side Stand
91	Brake Pad Wear
94	Battery
96	Fuse Replacement
99	Bulb Replacement

page

106	TRANSPORTING
107	CLEANING
110	STORAGE GUIDE
110	Storage
112	Removal from Storage
113	SPECIFICATIONS
117	CATALYTIC CONVERTER