

FREQUENCY ITEM		WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE(1)]								REFER TO PAGE
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
		MONTH		6	12	18	24	30	36		
*	DRIVE BELT				I	R		I	R	—	
	BELT CASE AIR CLEANER			C	C	C	C	C	C	80	
*	FINAL DRIVE OIL	(NOTE 5)								—	
	BRAKE FLUID	(NOTE 4)			I	I	R	I	I	18	
	BRAKE PAD WEAR				I	I	I	I	I	91, 92	
	BRAKE SYSTEM		I		I		I		I	18, 91, 92	
*	BRAKE LIGHT SWITCH				I		I		I	—	
*	BRAKE LOCK OPERATION		I	I	I	I	I	I	I	93	
*	HEADLIGHT AIM				I		I		I	—	
**	CLUTCH SHOE WEAR				I	I	I	I	I	—	
	SIDE STAND				I		I		I	90	
*	SUSPENSION				I		I		I	—	
*	NUTS, BOLTS, FASTENERS		I		I		I		I	—	
**	WHEELS/TYRES				I		I		I	—	
**	STEERING HEAD BEARINGS		I		I		I		I	—	