


PARKING THE MOTORCYCLE ON THE SIDE STAND (G, IIG, ND, FI)

Observe the following sequence:

- Turn off the engine.
- Get off the motorcycle to the left side, holding the vehicle in an upright position.
- Turn the handlebars fully to the left.
- Swing the side stand (1) down against the spring tension as far as it will go, and hold it in that position with your foot.
- Lean the motorcycle slowly to the left until it rests on the side stand.



(1) Side Stand

CAUTION:

- * **This side stand is designed to retract even if the motorcycle is raised only partially. Be sure to remember this, when you use the side stand.**

Instructions

- Be sure the side stand is pushed down to its furthest possible position before you apply weight to it.
- Select a flat surface for parking. If possible park the motorcycle on incline with its front end pointing uphill. If necessary, place the transmission in first gear to prevent the motorcycle from rolling away.
- Use the side stand only on firm ground.
- Avoid parking the motorcycle in locations near heavy pedestrian traffic.

▲ WARNING

- * **Do not operate the side stand while sitting on the motorcycle. It is difficult to erect the side stand fully while sitting on the motorcycle, and you may fall.**