


BRAKE SHOE WEAR

Refer to the Safety Precautions on page 61 .

The front and rear brakes are equipped with brake wear indicators.

When the brake is applied, an arrow (1) attached to the brake arm (2) moves toward a reference mark (3) on the brake panel (4). If the arrow aligns with the reference mark on full application of the brake, the brake shoes must be replaced.

See your Honda dealer for this service.



(1) Arrow

(2) Brake arm

(3) Reference mark

(4) Brake panel