

MAINTENANCE

Page

47 MAINTENANCE

48 Maintenance Schedule

50 Serial Numbers

51 Colour Label

51 Maintenance Precautions

52 Air Cleaner

54 Spark Plug

56 Idle Speed

57 Brake Shoe Wear

58 Battery

59 Fuse Replacement

Page

61 TRANSPORTING

62 CLEANING

64 STORAGE GUIDE

64 Storage

64 Removal from Storage

66 SPECIFICATIONS

69 NOISE CONTROL SYSTEM
(AUSTRALIA ONLY)

69 Tampering with noise control system
prohibited