


5. With the throttle closed, push the starter button (5). Release the starter button as soon as the engine starts.


NOTE:

- * Do not use the electric starter for more than 5 seconds at a time. Release the starter button for approximately 10 seconds before pressing it again.



(5) Starter button

6. Be sure to keep the throttle (6) closed and the rear brake (7) locked while starting and warming up the engine.
7. Allow the engine to warm up before riding (See "RIDING," page 38).



(6) Throttle