

ITEM	FREQUENCY	WHICHEVER COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]					Refer to pages
			WHICHEVER →					
			MONTH	x 1,000 km	x 1,000 mi	1	4	
	BRAKE SHOE WEAR			—	I	I	I	57
	BRAKE SYSTEM			I	I	I	I	13-14
*	BRAKE LIGHT SWITCH			—	I	I	I	—
*	HEADLIGHT AIM			—	I	I	I	—
**	CLUTCH SHOE WEAR			—	—	I	—	—
*	SUSPENSION			—	I	I	I	—
*	NUTS, BOLTS, FASTENERS			I	—	I	—	—
**	WHEEL/TYRES			—	I	I	I	—
**	STEERING HEAD BEARINGS			I	—	—	I	—

* SHOULD BE SERVICED BY YOUR AUTHORIZED HONDA DEALER UNLESS THE OWNER HAS PROPER TOOLS AND SERVICE DATA AND IS MECHANICALLY QUALIFIED. REFER TO THE OFFICIAL HONDA SERVICE MANUAL.

** IN THE INTEREST OF SAFETY, WE RECOMMEND THESE ITEMS BE SERVICED ONLY BY AN AUTHORIZED HONDA DEALER.

NOTE: (1) For higher odometer readings, repeat at the frequency interval established here.

(2) Service more frequently when riding in unusually wet or dusty areas.