

MAINTENANCE

TOOL KIT

The tool kit is under the rear seat (page 55).

Some roadside repairs, minor adjustments and parts replacement can be performed with the tools contained in the kit.

- Spark plug wrench
- 17 mm Box end wrench
- 10 × 12 mm Box end wrench
- 8 mm Open end wrench
- Extension bar
- Pliers
- Screwdriver handle
- No. 2 Phillips screwdriver
- No. 2 screwdriver
- 5 mm Hex wrench
- 10 mm Box wrench
- 0.7 mm Feeler gauge
- Fuse puller
- Tool bag

