

# MAINTENANCE

## Page

### **44 MAINTENANCE**

45	Maintenance Schedule
48	Tool Kit
49	Serial Numbers
50	Maintenance Precautions
51	Air Cleaner
52	Crankcase Breather
53	Engine Oil
56	Spark Plugs
58	Throttle Operation
59	Idle Speed
60	Drive Chain
66	Front and Rear Suspension Inspection
66	Side Stand

## Page

67	Brake Pad Wear
69	Wheel Removal
74	Battery
77	Fuse Replacement
79	Stoplight Switch Adjustment
80	Bulb Replacement

### **84 CLEANING**

### **86 STORAGE GUIDE**

86	Storage
88	Removal From Storage

### **89 SPECIFICATIONS**

### **92 CATALYTIC CONVERTER**