


## Stop/Taillight Bulb

1. Remove the taillight lens (1) by removing the two screws (2).
2. Slightly press the bulb (3) and turn it counterclockwise.
3. Install a new bulb in the reverse order of removal.




(1) Taillight lens  
(2) Screws

(3) Bulb

## Front/Rear Turn Signal Bulb

1. Remove the turn signal lens (1) by removing the screw (2).
2. Remove the socket (3) by turning it counterclockwise.
3. Pull out the bulb (4).
4. Install a new bulb in the reverse order of removal.



(1) Turn signal lens  
(2) Screw

(3) Socket  
(4) Bulb