

Engine Stop Button

The engine stop button (1) is next to the right handlebar grip. Press the button until the engine stops completely.

