

MAINTENANCE SCHEDULE

Perform Pre-ride Inspection (Page 54) at each scheduled maintenance period.

I: Inspect and Clean, Adjust, Lubricate or Replace if necessary.

C: Clean R: Replace A: Adjust L: Lubricate

ITEM	FREQUENCY	EVERY	BREAK-IN MAINT.	REGULAR MAINT. INTERVAL	Refer to
			200 mi 350 km	1000 mi 1600 km	
*	FUEL LINE			I	—
*	THROTTLE OPERATION			I	100
	AIR CLEANER	NOTE 1		C	98
	SPARK PLUG			I	88
*	VALVE CLEARANCE		I	I	90
	ENGINE OIL		R	R	78
	ENGINE OIL STRAINER SCREEN			C	80
*	ENGINE OIL CENTRIFUGE FILTER			C	84
*	CAM CHAIN TENSION		A	A	96
*	CARBURETOR IDLE SPEED		I	I	102