

## Oil change and oil strainer screen cleaning:

Drain the oil while the engine is still warm.

1. Remove the skid plate (1) and engine cushion rubber (2).
2. Remove the oil filler cap.
3. Place an empty oil drain pan under the engine and remove the oil strainer cap (3).
4. Operate the kick starter several times to aid in complete draining of the remaining oil.

