

Clutch

Clutch adjustment may be required if the motorcycle stalls when shifting into gear or tends to creep, or if the clutch slips, causing acceleration to lag behind engine speed.

Normal clutch lever free play should be 10-20 mm (0.4 -0.8 in) at the lever (1).

