

I: Inspect and Clean, Adjust, Lubricate or Replace, if necessary C: Clean R: Replace A: Adjust		INITIAL SERVICE PERIOD (First week of operation)	REGULAR SERVICE PERIOD (Every 30 operating days)	Refer to page
	FUEL LINE	I: (EVERY YEAR)		—
*	FUEL STRAINER	C: (EVERY YEAR)		42
	THROTTLE OPERATION	I	I	54
	DRIVE CHAIN	I	I	55
*	FRONT & REAR BRAKE SHOES	I: (EVERY YEAR)		—
	FRONT & REAR BRAKE SYSTEM	I	I	51
*	CLUTCH	A	A	50
*	SPARK ARRESTER		C	58
	ALL NUTS, BOLTS, FASTENERS	I	I	—
	LIGHTING EQUIPMENT	I	I	—
	TIRES	I	I	20
*	STEERING HEAD BEARING	A: (EVERY YEAR)		—
*	REVERSE LOCK MECHANISM	I	I	—