

## PARKING

1. Stop the vehicle, shift the transmission into neutral, turn the fuel valve, fuel cap lever, and ignition switch OFF.
2. Pull the parking brake lever and lock it. (See page 14.)

### WARNING

- \* *Do not park on an incline. If you must park on a hill, place the **FOUR TRAX** across the incline so that it neither faces downhill nor uphill.*