


Shifting Gears

UPSHIFTING SEQUENCE



DOWNSHIFTING SEQUENCE

Your ATV has five forward gears: 1, 2, 3, 4, and 5.

The gearshift pedal is located near the left footpeg. One full stroke of the pedal shifts the transmission to the next higher or lower gear in the shifting sequence. The pedal automatically returns to the horizontal position when released.

To upshift to a higher gear, put the toe of your boot under the gearshift pedal and raise the pedal one full stroke. To downshift, step on the gearshift pedal and depress the pedal one full stroke.