

## BATTERY

It is not necessary to check battery electrolyte level or add distilled water as the battery is a sealed type. If any loss of electrolyte is experienced or if your battery seems to be weak, causing slow starting or other electrical troubles, see your authorized Honda dealer.



### WARNING

- \* *Even though the battery is sealed, it still vents explosive gases. Do not allow open flames or sparks near the battery.*

### CAUTION:

- \* *Do not attempt to remove the caps from the cells.*
- \* *When the FOURTRAX is to be stored for an extended period of time, remove the battery from the vehicle and charge it fully. Then store it in a cool, dry place. If the battery is to be left on the vehicle, disconnect the negative cable from the battery terminal.*