

## MAINTENANCE AND REPAIRS

### MAINTENANCE SCHEDULE

		EVERY	SERVICE PERIOD		Refer to page
			INITIAL (First week of operation or 30 operating hours) (NOTE 1)	REGULAR (Every 30 operating days or 100 operating hours) (NOTE 1)	
I: Inspect and Clean, Adjust, Lubricate or Replace if necessary. C: Clean    R: Replace A: Adjust    L: Lubricate					
*	FUEL LINE	YEAR I			—
*	FUEL STRAINER SCREEN	YEAR C			88, 89
*	THROTTLE OPERATION		I	I	90
*	CARBURETOR CHOKE			I	95
	AIR CLEANER	(NOTE 2)		C	91—93
	AIR CLEANER CASE DRAIN TUBE	(NOTE 3)		I	94
	SPARK PLUG			I	104, 105
*	VALVE CLEARANCE		I	I	105
	ENGINE OIL		R	R	28, 98—102
	ENGINE OIL FILTER		R	R	100—102
*	ENGINE IDLE SPEED		I	I	95—97
	REAR FINAL GEAR CASE OIL	YEAR I, 2 YEARS R			103
	BRAKE FLUID	(NOTE 4)		I	117, 118