

High altitude fuel mixture adjustment .....	97
Refueling .....	84
Reserve fuel supply .....	27
<b>Fuses</b>	
Location .....	111
Replacement .....	111

## **G**

Gasoline (see Fuel)	
Gearshift pedal .....	23
Gearshifting .....	23, 59

## **H**

Headlight switches .....	20
Helmet holder .....	29
High altitude fuel mixture adjustment .....	97
<b>Hills</b>	
Riding across slopes .....	74
Riding down hills .....	72
Riding up hills .....	65
Stopping on hills .....	67
Turning on slopes .....	75

## **I**

Idle speed adjustment .....	95
Ignition switch .....	13
<b>Indicator lamps</b>	
Neutral indicator lamp .....	22
Reverse indicator lamp .....	22
Inspection, pre-ride .....	36

## **K**

Kick starter .....	17
--------------------	----

## **L**

<b>Loading</b>	
Loading guidelines and procedures .....	40
Weight limits .....	39
Lubrication (see Engine oil and Final drive oil)	

## **M**

<b>Maintenance</b>	
--------------------	--