

## S

Safety messages, special .....	1
Seat removal and installation .....	130
Serial numbers.....	148
Shifting gears .....	23, 61
Skid plates .....	131
Skidding.....	66
Spark arrester.....	132
Spark knock .....	88
Spark plug .....	106
Specifications.....	142
Stalling on a hill .....	69
Starter button .....	16
Starting primer knob.....	16
Storage compartment.....	31
Storing procedures .....	139

## T

Throttle	
Cable .....	92
Lever.....	19, 92
Tires	
Inflation and air pressure .....	126
Repairing.....	129
Specifications .....	127
Tread condition .....	128
Tool kit .....	80
Trailer hitch .....	30
Trailer towing	
Operational guidelines.....	40
Weight limits.....	39
Transporting procedures.....	134
Turning	
On level ground.....	64
On slopes .....	77

## V

Valve clearance .....	107
-----------------------	-----