

### Digital Clock (Canadian model only)

When selected, the digital clock (1) (Fig. 2-19) shows the time while the ignition is ON ( I ). To change the display from hourmeter to digital clock, press and release the hourmeter/digital clock select button (2).




Fig. 2-19 (1) Digital clock (2) Hourmeter/digital clock select button

### Digital Clock Adjustment:

Turn the ignition switch ON ( I ).

Press and hold the hour select button (1). After two seconds, the hour display will begin advancing automatically. Release the button when the display reaches the desired hour (2).

Press and hold the minute select button (3). After two seconds, the minute display will begin advancing automatically. Release the button when the display reaches the desired minute (4).




Fig. 2-20 (1) Hour select button (2) Hour (3) Minute select button (4) Minute