

# Maintenance Schedule

Maintenance Procedures:

I: inspect and clean, adjust, lubricate, or replace, if necessary

C: clean

A: adjust

L: lubricate

R: replace

ITEMS		FREQUENCY	WHICHEVER COMES FIRST		INITIAL MAINT.	REGULAR MAINT. INTERVAL		Refer to page	
			⇔	mi	100	600	1200		
				km	150	1000	2000		
			NOTE	HOURS	20	100	200		
EMISSION RELATED ITEMS	*	FUEL LINE					I	—	
	*	THROTTLE OPERATION					I	116	
	*	CARBURETOR CHOKE					I	118	
		AIR CLEANER	NOTE 1				C	C	111
		AIR CLEANER HOUSING DRAIN TUBE	NOTE 2				I	I	115
		SPARK PLUG					I	I	122
	*	VALVE CLEARANCE					I	I	125
		ENGINE OIL			R	R	R	R	100
		ENGINE OIL FILTER			R	R	R	R	104
	*	ENGINE IDLE SPEED			I	I	I	I	121

\* Should be serviced by your Honda dealer, unless you have the proper tools and service data and are mechanically qualified. Refer to the official Honda Service Manual (page 200 ).