

TIRES

Although the tires are designed specifically for vigorous offroad use, they are not immune to punctures. Always select your riding area with care.

WARNING

- * *The TRX is not designed to be driven on paved surfaces. Handling and control will be severely affected.*
- * *This TRX is a 4-wheel drive model. Use of different sizes of tires or uneven tire pressure will adversely affect the stability and control of the vehicle.*

Check the tire pressure frequently with the air pressure gauge supplied with the TRX.

For normal use, the tires should be inflated to the recommended pressure. A manually operated tire pump should be used rather than the high pressure systems found in service stations. This will minimize the possibility of tire damage from overinflation.

NOTE:

- * Tire pressure should be checked when the tires are "cold," before you ride.
- * Check tire pressure before you ride.

TIRE SIZE		24 x 9.00-11
STANDARD TIRE BRAND	FRONT	OHTSU A/T 502
	REAR	
RECOMMENDED PRESSURE		2.2 psi (15 kPa, 0.15 kg/cm ²)
MAX. PRESSURE		2.6 psi (18 kPa, 0.18 kg/cm ²)
MIN. PRESSURE		1.8 psi (12 kPa, 0.12 kg/cm ²)
At loaded		2.2-3.1 psi (15-21 kPa, 0.15-0.21 kg/cm ²)

WARNING

- * *Maintain proper tire air pressure. Improperly inflated tires may adversely affect maneuverability and may cause loss of control.*
- * *When replacing tires use only the size, type and brand identified in the chart. The use of different sizes or types of tire can severely effect vehicle handling.*