

# Maintenance Schedule

ITEMS		FREQUENCY	WHICHEVER COMES FIRST		INITIAL MAINT.	REGULAR MAINT. INTERVAL		Refer to page
			mi	km	100	600	1200	
			⇔		150	1000	2000	
			NOTE	HOURS	20	100	200	
NON EMISSION RELATED ITEMS		DRIVESHAFT BOOTS (TRX350FE only)						156
		REAR FINAL GEAR CASE OIL AND DIFFERENTIAL OIL (TRX350FE only)				R: (EVERY 2 YEARS)		114, 116
	*	BRAKE FLUID	NOTE 3					134
	*	BRAKE SHOE WEAR	NOTE 1					145
		BRAKE SYSTEM						134
	*	REVERSE LOCK SYSTEM						127
		SKID PLATES, ENGINE GUARD						155
	*	CLUTCH SYSTEM						126
	*	SUSPENSION						--
	*	SPARK ARRESTER				C	C	133
	*	NUTS, BOLTS, FASTENERS						--
	**	WHEELS/TIRES						147
	**	STEERING SHAFT HOLDER BEARINGS						--
	**	STEERING SYSTEM						--

\* Should be serviced by your Honda dealer, unless you have the proper tools and service data and are mechanically qualified. Refer to the official Honda Service Manual (page 214 ).

\*\* In the interest of safety, we recommend these items be serviced only by your Honda dealer.