

Storing Your Honda

Preparation for Storage

Refer to *Safety Precautions* on page 85 .

This procedure requires a means for draining and disposing of drained fuel (page 164).

1. Change the engine oil and filter (page 104).
2. Fill the fuel tank. Make sure the fuel fill cap is properly installed.
3. Check that the fuel valve is OFF.
4. Drain the carburetor into an approved petrol container and dispose of it in an approved manner (page 164).

If storage will last longer than one month, carburetor draining is important, to assure proper performance after storage.

WARNING

Petrol is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine and keep heat, sparks and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.

(cont'd)