


Tool Kit

The tool kit (1) is stored on the underside of the seat (2) (page 86), fastened with a rubber band (3).

The tools in the kit are sufficient to perform routine maintenance and simple repairs. Any extensive work requiring additional tools should be performed by your Honda dealer.

The tool kit includes the following items:

- * standard/Phillips screwdriver
- * screwdriver handle
- * spark plug wrench
- * air pressure gauge
- * tool bag



(1) tool kit
(2) seat

(3) rubber band