

P	
Parking.....	94
Parts location.....	10
Parking brake.....	33
Passenger carrying.....	56
Pavement, no riding on.....	58
Pinging.....	102
Pre-ride inspection.....	46
R	
Rear final gear case oil.....	117
Recoil starter.....	19
Reverse	
Assist cable.....	123
Assist lever.....	123
Gear, shifting into.....	31, 71
Indicator.....	22
Riding in reverse.....	76
Selector knob.....	32
Rider training course.....	1, 46
S	
Safety messages, special.....	1
Seat removal and installation.....	146
Serial numbers.....	166
Shifting gears.....	31, 71
Switch	
Downshift switch.....	31, 71
Upshift switch.....	31, 71
Skid plates.....	147
Skidding.....	80
Socket, accessory.....	42
Spark arrester.....	148
Spark knock.....	102
Spark plug.....	120
Specifications.....	160
Stalling on a hill.....	83
Starter button.....	17
Starting primer knob.....	18
Storage compartment.....	41
Storing procedures.....	157