


Storing Your Honda

- Pour a tablespoon (15 – 20 cc) of clean engine oil into cylinder and cover the spark plug hole with a piece of cloth.
 - With the engine stop switch in the OFF () position, depress the kickstarter several times to crank the engine and distribute the oil.
 - Reinstall the spark plug and spark plug cap.
7. Wash and dry your ATV. Wax all painted surfaces.
 8. Lubricate the drive chain (page 150).
 9. Inflate the tires to their recommended pressures (page 139).
 10. Store your ATV in an unheated area, free of dampness, away from sunlight, with a minimum of daily temperature variation.
 11. Place your ATV on blocks to lift both tires off the floor.
 12. Cover your ATV with a porous material. Avoid using plastic or similar non-breathing, coated materials that restrict air flow and allow heat and moisture to accumulate.