

Instruments & Controls

This section shows the location of all indicators and controls you would normally use before or while riding your ATV.

The items listed on this page are described in this section. Instructions for other components are presented in other sections of this manual where they will be most useful.

Component Locations	10
Indicator	13
High Coolant Temperature Indicator	13
Controls & Features	14
Fuel Valve	14
Choke Lever	15
Hot Start Lever	16
Ignition Switch	17
Kickstarter	18
Engine Stop Switch	19
Headlight Switch	20
Headlight Dimmer Switch	20
Throttle Lever	21
Clutch Lever	21
Front Brake Lever	22
Rear Brake Pedal	22
Parking Brake	23
Flag Pole Bracket	24