

MAINTENANCE SCHEDULE

	FREQUENCY	ITEMS	Whichever comes first ⇒	INITIAL	REGULAR		Refer to page	
				MAINTENANCE	MAINTENANCE INTERVAL			
				mi	600	1200		
				100	1000	2000		
			NOTE	km	150	1000		
				HOURS	20	100		
EMISSION RELATED ITEMS	*	FUEL LINE				I	—	
	*	THROTTLE OPERATION				I	98	
	*	CARBURETOR CHOKE				I	103	
		AIR CLEANER	(NOTE 1)			C	C	99—101
		AIR CLEANER HOUSING DRAIN TUBE	(NOTE 2)			I	I	102
		SPARK PLUG				I	I	114—115
	*	VALVE CLEARANCE			I	I	I	115
		ENGINE OIL			R	R	R	35, 106—110
		ENGINE OIL FILTER			R	R	R	106—110
	*	ENGINE IDLE SPEED			I	I	I	104

- I: Inspect and Clean, Adjust,
Lubricate or Replace if necessary.
C: Clean R: Replace
A: Adjust L: Lubricate