

Cleaning.....	163
Climbing hills	85
Consumer information	171
Cooling system	
Checking coolant level and adding coolant	129
Coolant recommendations	130
Coolant replacement.....	131
Crossing slopes.....	94
Customer service	173

D

Differential oil.....	124
Digital clock	31
Dimmer switch	21
Dipstick	42, 117
Display (see Multi-function display)	24
Drive mode select switch.....	34
Driveshaft boots.....	159

E

Emission control system	171
Engine	
Idle speed adjustment.....	115
Break-in procedures	ii
Flooded engine.....	76
Starting the engine	73
Engine guard and skid plates	156
Engine oil	
Changing oil.....	120
Checking oil level and adding oil.....	117
Oil filler cap.....	42, 117
Oil filter	120
Oil/coolant high temperature indicator.....	22
Recommendations	119
Engine stop switch	15
Exhaust system	
Cleaning	53
Purging.....	157