

Oil Change Indicator

The oil change indicator (1) (Fig. 2-18) appears in the display when the mileage or operating hours on your FOURTRAX approaches the oil change interval specified on the maintenance schedule.

Reset the indicator after each oil change.

To reset the indicator, press and hold both the odometer/tripmeter and hourmeter/digital clock select buttons for more than 2 seconds. The indicator will disappear.

If you change oil before the oil change indicator appears, be sure to reset the oil change indicator after changing the oil. The indicator will appear for 2 seconds then disappear. This means the indicator is reset.




Fig. 2-18 (1) Oil change indicator