

# **GPScape System (TRX500FGA only)**

---

This section explains the GPScape navigation system. Instructions for the topics listed on this page are included.

Introduction .....	44
Important Safety Information .....	47
System Limitations.....	48
System Start-up.....	49
Position Fix .....	49
System Failure to Display a Position Fix .....	50
Satellite Status .....	52
GPS Mode.....	54
GPS Mode Display.....	56
Waypoint Number Display .....	57
Direction to Waypoint Display .....	58
Distance to Waypoint .....	60
Basic Waypoint Selection .....	61
Advanced Waypoint Selection.....	63
Determining the Coordinates of Your Current Position.....	67
Compass Direction Indicator.....	68
Automatic Clock Adjustment.....	70