

Maintenance Schedule

Maintenance Procedures:

I: inspect and clean, adjust, lubricate, or replace, if necessary

C: clean

A: adjust

L: lubricate

R: replace

ITEMS	FREQUENCY	WHICHEVER COMES		INITIAL MAINT.	REGULAR MAINT. INTERVAL		Refer to page
		FIRST ⇒	mi	100	600	1200	
			km	150	1000	2000	
		NOTE	HOURS	20	100	200	
*	FUEL LINE				I		—
*	THROTTLE OPERATION				I		129
*	CARBURETOR CHOKE				I		131
	AIR CLEANER	NOTE 1			C	C	123
	AIR CLEANER HOUSING DRAIN TUBE	NOTE 2			I	I	128
	SPARK PLUG				I	I	135
*	VALVE CLEARANCE			I	I	I	138
	ENGINE OIL			R	R	R	110
	ENGINE OIL FILTER			R	R	R	115
*	ENGINE IDLE SPEED			I	I	I	134

* Should be serviced by your Honda dealer, unless you have the proper tools and service data and are mechanically qualified. Refer to the official Honda Service Manual (page 220).