



Indicators & Displays

7	Multi-function display	The display includes the following functions. <i>Display Check</i> .
	Gear position indicator	Shows the gear position (page 19).
	Speedometer	Shows riding speed.
	Fuel gauge	Shows approximate fuel supply available (page 26).
	Oil change indicator	Lights when specified maintenance interval for engine oil change is reached (page 20).
	Odometer	Shows accumulated mileage (page 21).
	Tripmeter	Shows mileage per trip (page 21).
	Hourmeter	Shows hours and tenths of hours of engine operation (page 23).
	Digital clock	Shows the time (hours and minutes) (page 24).
8	Hour select button	Advances the hour displayed by the digital clock (page 24).
9	Minute select button	Advances the minutes displayed by the digital clock (page 24).
10	Adjust button	Used to set the digital clock (page 24).
11	PS (Electric Power Steering) indicator (TRX500FPE only)	Lights when there is an abnormality in the PS (Electric Power Steering) system. See page 45 . <i>Lamp Check</i> .