


# Indicators & Displays

The indicators and displays on your ATV keep you informed, alert you to possible problems, and make your riding safer and more enjoyable. Refer to the indicators frequently. Their functions are described on the following pages.



- |  |                                       |
|--|---------------------------------------|
| (1) reverse indicator                      | (6) minute select button              |
| (2) neutral indicator                      | (7) hour select button                |
| (3) oil/coolant high temperature indicator | (8) multi-function display            |
| (4) 4WD indicator                          | (9) adjust button                     |
| (5) hourmeter/digital clock select button  | (10) odometer/tripmeter select button |

## Lamp Check

The oil/coolant high temperature indicator comes on when you turn the ignition switch ON so you can check that it is working. The indicator remains on until after the engine is started.

This indicator is identified in the table on page 16 with the words: *Lamp Check*.