

Maintenance Schedule

Maintenance Procedures:

I: inspect and clean, adjust, lubricate, or replace, if necessary

C: clean

A: adjust

L: lubricate

R: replace

ITEMS		FREQUENCY	WHICHEVER	INITIAL	REGULAR		Refer to page	
			COMES	MAINT.	MAINT. INTERVAL			
			FIRST	100	600	1200		
			⇨	mi	150	1000		2000
		NOTE	HOURS	20	100	200		
EMISSION RELATED ITEMS	*	FUEL LINE				I	—	
	*	THROTTLE OPERATION				I	134	
	*	CARBURETOR CHOKE				I	136	
		AIR CLEANER	NOTE 1			C	C	129
		AIR CLEANER HOUSING DRAIN TUBE	NOTE 2			I	I	133
		SPARK PLUG					I	138
	*	VALVE CLEARANCE			I	I	I	141
		ENGINE OIL			R	R	R	112
		ENGINE OIL FILTER			R	R	R	117
	*	ENGINE IDLE SPEED			I	I	I	137
		RADIATOR COOLANT	NOTE 3			I	I	124
	*	COOLING SYSTEM	NOTE 2			I	I	—

- * Should be serviced by your Honda dealer, unless you have the proper tools and service data and are mechanically qualified. Refer to the official Honda Service Manual (page 220).