



Basic Operation & Riding

This section gives basic riding instructions, including how to start and stop your engine, how to use the throttle and brakes, and what to do when you're through riding.

To protect your new engine and enjoy optimum performance and service life, refer to Break-in Guidelines (page 198).

Safe Riding Precautions	43
Off-road Use Only	43
Keep Hands and Feet on Controls.....	44
Control Speed.....	45
Use Care on Unfamiliar or Rough Terrain.....	46
Do Not Perform Stunts.....	47
Starting & Stopping the Engine	48
Preparation	49
Starting Procedure.....	50
Flooded Engine	51
Bank Angle Sensor Ignition Cut-off System	51
How to Stop the Engine	52
Shifting Gears	53
Riding in Reverse.....	55

(cont'd)

