


Choke Lever

The choke lever (1) is on the left side of the carburetor.

Raising the choke lever will close the choke valve. When the lever is raised, the carburetor delivers a rich fuel mixture for starting the engine when cold. Lower the lever to open the choke valve as the engine attains normal operating temperature.




(1) Choke lever

Storage Compartment

The storage compartment (1) is located on the left side of the frame. The Owner's Manual and tool kit should be stored in this compartment.

When washing the TRX 70, be careful not to flood this area with water.



(1) Storage compartment