

## **Flooded Engine**

If the engine does not start after several attempts, it may have become flooded with excess fuel. To clear the engine, turn the engine stop switch off, push the choke lever down completely, hold the throttle fully open, and pull the recoil starter rope several times. When the engine is cleared, turn the ignition switch on and repeat the normal starting procedure, but do not use the choke.

## **BREAK-IN**

During the first few days of riding, operate your new TRX so that the engine neither pulls laboriously nor approaches maximum rpm in any gear. Avoid full throttle operation, and shift gears frequently to vary engine speed. Careful break-in during the initial operating period will measurably extend the service life of the engine.