


**6. Engine stop switch.**

Check for proper function (pages 22–23 ).

RUN



OFF

