

Indicator & Controls

This section shows the location of all indicators and controls you would normally use before or while riding your ATV.

The items listed on this page are described in this section. Instructions for other components are presented in other sections of this manual where they will be most useful.

Component Locations	14
Indicator	17
Neutral Indicator	17
Operating Controls	18
Fuel Valve	18
Choke Lever	19
Ignition Switch	20
Engine Stop Switch	21
Recoil Starter.....	22
Throttle Lever	23
Front Brake Lever	24
Rear Brake Lever	24
Rear Brake Pedal.....	25
Parking Brake.....	26
Flag Pole Braket.....	27

(cont'd)