


# Engine Idle Speed and Air-Fuel Mixture



## Air-Fuel Mixture Adjustment

Air screw (2) is available to compensate for air-fuel mixture. For those who are mechanically proficient and have the necessary tools, adjustment procedures are given in the official Honda Shop Manual available from your dealer. All others should have this carburetor modification performed by your dealer.

